

# FINAL FANTASY VII REMAKE SHINRA CONTROLLER DISPLAY STAND

PRIMA  
EDIZIONE




Before you begin, remove the packaging film and any protective films you find on the various elements of the stand. They are marked with the sticker "REMOVE THIS FILM". Absolutely DO NOT remove the WHITE film attached under the gold mirrored base plate.

Protective film are on:


- the upper part of the base (A);
- the lower part of the base (B);
- both sides of supports (C)

(A) mirrored gold base




Attention! The back of this base has a WHITE protective film.  
DO NOT remove it or damage it for any reason.

(B) black base



## (C) supports



## Assembly instructions:

Remove the protective films on the various plexiglass elements. Be careful NOT to remove the WHITE film attached under the gold mirror plate (A).

Insert the supports (C) into the base (A), pushing them perpendicularly until they reach the end. The backs of the stands always go toward the back of the stand. Always refer to the photo on the front page to clear up any doubts!

Next, insert the new part into the base (A). The text "Shinra Electric Power Company" must be in the lower left corner while the serial number in the upper right corner.

### Please note:

The stand is made of plexiglass, so it is fragile. Be careful when handling it!

The various elements of the stand are joined by a firm interlock. They are not held together in any way by adhesive or double-sided tape. If you need to move the stand from one place to another, for added safety we recommend that you always keep one hand under the base to prevent pieces from accidentally falling off.